



DASH INSTALLATION INSTRUCTIONS

ALL MODELS (also see www.dashworksbyPaulatkins.com)

STEP ONE

REMOVE WINDSHIELD

STEP TWO

CUT ALONG EDGE OF THE ORIGINAL DASH LEAVING A 1" LIP



STEP THREE

DRILL SPOT WELDS UNDER BOTTOM EDGE OF DASH AND REMOVE ORIGINAL DASH



STEP FOUR

SET NEW DASH IN PLACE

STEP FIVE

DRILL THROUGH DASH INTO COWL AREA WHERE ORIGINAL DASH WAS SPOT WELDED



STEP SIX

BOND METAL TABS TO BOTTOM OF DASH USING *FIBER-ALL, KITTY HAIR* OR SIMILAR MATERIAL (Epoxy Glue) AND SCREW TO BOTTOM OF COWL

STEP SEVEN

BEFORE RE-INSTALLING WINDSHIELD, BLACK BOTTOM EDGE OF WINDSHIELD ON INSIDE, EVEN WITH TOP OF DASH



1369 COUNTY ROAD 649, HANCEVILLE, ALABAMA 35077

PHONE (256) 352-9608 FAX (256) 352-9618